








The (→) mark shows the piping direction.





Wireless remote control (ARC466A6)



Including mounting plate



Required space for service and ventilation



Standard location of holes in the wall